

## SEARCHING FOR YOUR CODE

---

If your home entertainment device does not respond to the Polaris Remote Control after trying all of the codes listed for your brand, or if your brand is not listed at all, try searching for your code.

To search for a code for your TV:

1. Turn on your TV.
2. On the remote control, press **TV** once; it blinks once. Then press and hold **SETUP** until the **TV** key blinks twice.



3. Enter **9 9 1**. The **TV** key blinks twice.



4. Continually press and release **CH+** until the TV turns off. Stop when the TV turns off.



5. Press **SETUP** once to lock in the code. The **TV** key blinks twice.

